Operating instructions for: Viper

Headrest (optional):
To adjust the height of the headrest, push in the push button located on the right side of the headrest and move the headrest up or down to desired height. To adjust the angle of the headrest, pivot the frame to desired position.

Lumbar:
Reach behind the backrest with both hands to slide the lumbar pad up and down to desired position.

Armrest height:
To adjust the height of the armrests, push the lever located at the bottom rear of the armrest outward to unlock the armrest. Raise or lower the armrests to the desired position and then push the lever back in until it clicks into locked position.

Chair height:
To raise the chair, lift body weight off of the chair while lifting the lever under the right side of the seat. To lower the chair, sit in seat while raising the same lever until desired height is reached then let go.

Recline angle:
To recline the chair, lift the lever under the left side of the seat to unlock the chair while leaning backwards. At desired position, push the lever forward until the chair clicks into the locked position.

Note: when unlocking the chair in a reclined position, the chair will not automatically spring forward. As a safety measure, the user must lean back to unlock the backrest and then it will follow the user forward.

Recline tension:
The tension of the spring which regulates the recline motion may be adjusted for different body weights. To adjust the tension, turn the hand-knob under the front of the chair clockwise to increase tension or counter clockwise to decrease tension.

300 Myrtle Avenue, Boonton, NJ 07005 **Telephone** 800-631-1186 **Facsimile** 800-220-3844
Web Site www.dauphin.com **My Valo** www.myvalo.com